




Computer Systems and Networks

ECPE 170 – Jeff Shafer – University of the Pacific

MIPS Assembly (Arithmetic, Branches)

Person of the Day – John Cocke



- Computer architecture pioneer
 - “Father of RISC Architecture”
 - Developed IBM 801 processor, 1975-1980
- Winner, *ACM Turing Award*, 1987

RISC = Reduced Instruction Set Computing


Achieve higher performance with simple instructions that execute faster

Person of the Day – John Hennessy




- Computer architecture pioneer
- Popularized RISC architecture in early 1980's
- Founder of MIPS Computer Systems in 1984
- Past president of Stanford University

Class to Date



Class Now



MIPS



MIPS Overview

- Family of computer processors first introduced in 1981
- **M**icroprocessor without **I**nterlocked **P**ipeline **S**tages
 - Original acronym
 - Now MIPS stands for nothing at all...

MIPS Products

- **Embedded devices**
 - Cisco/Linksys routers
 - Cable boxes
 - MIPS processor is buried inside *System-on-a-Chip (SOC)*

- **Gaming / entertainment**
 - Nintendo 64
 - Playstation, Playstation 2, PSP

- **Computers?**
 - Not so much anymore...
 - SGI / DEC / NEC workstations back in 1990's

MIPS Design


- RISC – **What does this mean?**
 - Reduced Instruction Set Computing
 - Simplified design for instructions
 - Use more instructions to accomplish same task
 - But each instruction runs much faster!

- 32 bits (originally) – **What does this mean?**
 - 1 “word”= 32 bits
 - Size of data processed by an integer add instruction
 - New(er) MIPS64 design is 64 bits, but we won’t focus on that

MIPS Assembly Programming



Quotes – Donald Knuth



“People who are more than casually interested in computers should have at least **some idea of what the underlying hardware is like**. Otherwise the programs they write will be pretty weird.”

– Donald Knuth

This is your motivation in the assembly labs!

Why Learn Assembly Programming?

- **Computer Science** track
 - Understand capabilities (and limitations) of physical machine
 - Ability to optimize program performance (or functionality) at the assembly level *if necessary*

- **Computer Engineer** track
 - Future courses (e.g. ECPE 173) will focus on processor design
 - Start at the assembly programming level and move into hardware
 - *How* does the processor implement the `add` instruction?
 - *How* does the processor know what data to process?

Instruction Set Architecture

- **Instruction Set Architecture (ISA)** is the interface between hardware and software
 - Specifies the format of processor instructions
 - Specifies the format of memory addresses (and addressing modes)
 - Specifies the primitive operations the processor can perform

Instruction Set Architecture

- ISA is the “contract” between the *hardware designer* and the assembly-level *programmer*
- Documented in a manual that can be hundreds or thousands of pages long
 - Example: Intel 64 and IA-32 Architectures Software Developers Manual
 - <http://www.intel.com/content/www/us/en/processors/architectures-software-developer-manuals.html>
 - No joke – the manual PDF (combined volumes) from Nov 2020 is **5066 pages long!**

Instruction Set Architecture

➤ Processor families share the same ISA

➤ Example ISAs:

- Intel x86
- Intel / AMD x86-64
- Intel Itanium
- ARM
- IBM PowerPC
- MIPS

All completely different,
in the way that C++, Java,
Perl, and PHP are all
different...

... and yet learning one
language makes learning
the next one much easier

Why MIPS?

- Why choose MIPS?
 - The MIPS ISA manual (volume 1, at least) is a svelte **108 pages!**
 - Extremely common ISA in textbooks
 - Freely available simulator
 - Common embedded processor
 - Good building-block for other RISC-style processors
 - Aligns with ECPE 173 course

Arithmetic Instructions

➤ Addition

```
add <result>, <input1>, <input2>
```

➤ Subtraction

```
sub <result>, <input1>, <input2>
```

Operation / "Op code"

Operands

Task : Write Code

➔ **Write MIPS assembly for**

$$f = (g+h) - (i+j)$$

```
add temp0, g, h  
add temp1, i, j  
sub f, temp0, temp1
```

Congratulations!

You're now an assembly
programming expert!


Data Sources

- Previous example was *(just a little bit)* fake...
 - We made up some variables:
`temp0, temp1, f, g, h, i, and j`
 - This is what you do when programming in C++
(or any high level language)

**Problem: You can't make up
variables in assembly!**
(as least, not in this fashion)

Data Sources

Where can we explicitly place data in assembly programming?



1. Registers

- On the CPU itself
- Very close to ALU
- Tiny
- Access time: 1 cycle

2. Memory

- Off-chip
- Large
- Access time: 100+ cycles


Aside – Cache

- **Review: Does the programmer explicitly manage the cache?**
- **Answer: No!**
 - The assembly programmer just reads/writes memory addresses
 - Cache is managed automatically in hardware
 - Result: Memory *appears* to be faster than it really is


ECPE 71

➔ From your knowledge of ECPE 71 (Digital Design), how would you construct a register?


Flip Flops! (*D Flip Flop shown*)



D	Q(t+1)
0	0
1	1



ECPE 71 – Group of Registers



Registers

- MIPS design: **32 integer registers**, each holding **32 bits**
 - “Word size” = 32 bits

Name	Use
\$zero	Constant value: ZERO
\$s0-\$s7	Local variables
\$t0-\$t9	Temporary results

- **This is only 19 – where are the rest of the 32?**
 - Reserved *by convention* for other uses
 - We’ll learn a few more later...

Problem 1: Write Code

➔ Write MIPS assembly using registers for:

$$f = (g+h) - (i+j)$$

Map:

```
$s0 = g  
$s1 = h  
$s2 = i  
$s3 = j  
$s4 = f
```

Code:

```
add $t0, $s0, $s1  
add $t1, $s2, $s3  
sub $s4, $t0, $t1
```

P1

More Arithmetic Instructions

➤ Add Immediate

```
addi <result>, <input1>, <constant>
```

Register

Register

Can be a positive or
negative number!

Code Example

➔ Write MIPS assembly using registers for:

$$f = g + 20$$

Map:

`$s0 = f`

`$s1 = g`

Code:

```
addi $s0, $s1, 20
```

MIPS Branches / Loops



Branches

- Branch on Equal (if \$1 == \$2, goto dest)

```
beq <reg1>, <reg2>, <destination>
```

- Branch on Not Equal (if \$1 != \$2, goto dest)

```
bne <reg1>, <reg2>, <destination>
```

- Branch on Greater Than (if \$1 > \$2, goto dest)

```
bgt <reg1>, <reg2>, <destination>
```

Branches

- Branch on Greater Than or Equal (if $\$1 \geq \2 , goto dest)

```
bge <reg1>, <reg2>, <destination>
```

- Branch on Less Than (if $\$1 < \2 , goto dest)

```
blt <reg1>, <reg2>, <destination>
```

- Branch on Less Than or Equal (if $\$1 \leq \2 , goto dest)

```
ble <reg1>, <reg2>, <destination>
```

Tests, Jump

- Set on Less Than (if $\$2 < \3 , set $\$1 = 1$, otherwise 0)

```
s1t <reg1>, <reg2>, <reg3>
```


- Jump (goto dest)

```
j <destination>
```


Code Example

➔ Write MIPS assembly for:

```
if (A == B)
{
    <equal-code>
}
else
{
    <not-equal-code>
}
<after-if-code>
```



Code Example

➔ Write MIPS assembly:

Map:`$s0 = A``$s1 = B`**Code:**`beq $s0, $s1, equal``<not-equal-code>``j done``equal: <equal-code>``j done``done: <after-if-code>`

Problem 2: Write Code

➔ **Write MIPS assembly for:**

Map:


```
$s0 = C  
$s1 = A  
$s2 = B
```

```
if ( (A>=B) || A>6 )  
    C=A;  
else  
    C=B-A;
```

Code Example

➔ Write MIPS assembly for:

```
while (A != B)
{
    <loop-body>
}
<post-loop-code>
```



Code Example

➔ Write MIPS assembly:

Map:`$s0 = A``$s1 = B`**Code:**

```
start:    beq $s0, $s1, done
          <loop-body>
          j  start
done:     <post-loop-code>
```

Problem 3: Write Code

➔ **Write MIPS assembly for:**

Map:
\$s0 = sum
\$t0 = i

```
sum=0;  
for (i=0; i<10; i++)  
{  
    sum+=i;  
}
```

Problem 4: Write Code

➔ **Write MIPS assembly for:**

Map:

\$s0 = sum

\$s1 = i

\$s2 = j

```
sum=0;
for (i=0; i<10; i++)
{
    j=i;
    while (j<2*i)
    {
        sum=sum+j;
        j++;
    }
}
```

P4

Problem 5: Write Code

➔ **Write MIPS assembly for:**

Map:

```
$s0 = sum  
$s1 = i
```

```
while (1)  
{  
    sum=sum+i;  
    i--;  
    if (i<=0)  
        break;  
    else  
        continue;  
}
```

P5

Demos and Resources



Demos

1. **QtSPIM** is a MIPS simulator
 1. Review installation tutorial
 2. Walkthrough of simulator with `example1.asm`

QtSpim

FP Regs Int Regs [16] Data Text

Int Regs [16]

PC = 0
EPC = 0
Cause = 0
BadVAddr = 0
Status = 3000fff10
HI = 0
LO = 0
R0 [r0] = 0
R1 [at] = 0
R2 [v0] = 0
R3 [v1] = 0
R4 [a0] = 0
R5 [a1] = 0
R6 [a2] = 7ffff4e4
R7 [a3] = 0
R8 [t0] = 0
R9 [t1] = 0
R10 [t2] = 0
R11 [t3] = 0
R12 [t4] = 0
R13 [t5] = 0
R14 [t6] = 0
R15 [t7] = 0
R16 [s0] = 0
R17 [s1] = 0
R18 [s2] = 0
R19 [s3] = 0
R20 [s4] = 0
R21 [s5] = 0
R22 [s6] = 0
R23 [s7] = 0
R24 [t8] = 0
R25 [t9] = 0
R26 [k0] = 0
R27 [k1] = 0

Text

User Text Segment [00400000]..[00440000]

```
[00400000] 8fa40000 lw $4, 0($29) ; 183: lw $a0 0($sp) # argc
[00400004] 27a50004 addiu $5, $29,
[00400008] 24a60004 addiu $6, $5, 4
[0040000c] 00040080 sll $2, $4, 2
[00400010] 00c20021 addu $6, $6, $2
[00400014] 0c000000 jal 0x00000000
[00400018] 00000000
[0040001c] 3402000a ori $2, $0, 10
[00400020] 0000000c syscall

Kernel Text Segment [80000000]..[80000000]
[80000180] 0001d821 addu $27, $0, $
[80000184] 3c019000 lui $1, -28672 ; 92: sw $v0 $1 # Not re-entrant and we can't
trust $sp
[80000188] ac220200 sw $2, 512($1)
[8000018c] 3c019000 lui $1, -28672 ; 93: sw $a0 $2 # But we need to use these
registers
[80000190] ac240204 sw $4, 516($1)
[80000194] 401a6800 mfc0 $26, $13 ; 95: mfc0 $k0 $13 # Cause register
[80000198] 001a2082 srl $4, $26, 2 ; 96: srl $a0 $k0 2 # Extract ExcCode Field
[8000019c] 3084001f andi $4, $4, 31 ; 97: andi $a0 $a0 0x1f
[800001a0] 34020004 ori $2, $0, 4 ; 101: li $v0 4 # syscall 4 (print_str)
[800001a4] 3c049000 lui $4, -28672 [__ml_] ; 102: la $a0 __ml_
[800001a8] 0000000c syscall ; 103: syscall
[800001ac] 34020001 ori $2, $0, 1 ; 105: li $v0 1 # syscall 1 (print_int)
[800001b0] 001a2082 srl $4, $26, 2 ; 106: srl $a0 $k0 2 # Extract ExcCode Field
[800001b4] 3084001f andi $4, $4, 31 ; 107: andi $a0 $a0 0x1f
[800001b8] 0000000c syscall ; 108: syscall
[800001bc] 34020004 ori $2, $0, 4 ; 110: li $v0 4 # syscall 4 (print_str)
[800001c0] 3344003c andi $4, $26, 60 ; 111: andi $a0 $k0 0x3c
[800001c4] 3c019000 lui $1, -28672 ; 112: lw $a0 __excp($a0)
[800001c8] 00240821 addu $1, $1, $4
[800001cc] 8c240180 lw $4, 384($1)
[800001d0] 00000000 nop ; 113: nop
[800001d4] 0000000c syscall ; 114: syscall
[800001d8] 34010018 ori $1, $0, 24 ; 116: bne $k0 0x18 ok_pc # Bad PC exception
```

**Single Step
Button!**
(Advance by 1 instruction)

Resources

- Many resources available on ECS website
- 1. The ***MIPS Example Programs*** page
(basic arithmetic, looping, I/O, and function calls)
 - 1. The `example1.asm` program – Good example of empty “stub program” template to use
- 2. The ***MIPS Instruction Set*** page
 - 1. Partial guide

Resources

- Files available in Canvas site (under ECPE 170)
 - **HP_AppA.pdf**
 - Appendix A from famous Hennessy & Patterson *Computer Organization* textbook
 - Assemblers, Linkers, and the SPIM simulator
 - Starting on page 51 is an overview of the MIPS assembly commands!
 - **MIPS_Green_Sheet.pdf**
 - “Cheat sheet” for expert programmers
 - MIPS commands, registers, memory conventions, ...